


KRP1B51 · 54 · 56 · 57 – adapter for wiring

Accessories

Check if the following accessories are included in the kit.



PC board support	x 4
Tie wrap	x 3
Installation manual	x 1


NOTE

- Kits vary according to applicable models.
- A special adaptor fixing plate and box are required for the following models.

FH(Y)C KRP1B94
 FVY KRP1B95


1 NAMES OF PARTS

Display output terminals



2 ELECTRIC WIRING


- Refer to the WIRING DIAGRAM attached to the indoor unit before attempting to wire.
 [Make sure wires to units do not pass over the PC board when wiring.]
- Wire the adaptor to the indoor unit as described below.



① Fetching the operation display signal


- Attaching an hour meter

Output is generated at the contact while the compressor is running.



- Fan ON display

Output is generated at the contact while the fan is running.




3 INSTALLATION

- Installation differs according to models as shown below.
- Do not bundle low and high voltage wires together.
- Bundle any excess wires with the attached tie wraps so as to keep loose wirings off the indoor unit PC board.

<< Ceiling-mounted cassette type >>


FH(Y)C (Multiflow type)

Fit the edge of the adaptor PCB into the grooves on the adaptor box.



NOTE: Optional adaptor box is required to install the adaptor.

FH(Y)K (Corner type)




« Ceiling suspended type »

FH(Y)

Adaptor (KRP1B54)

« Floor-standing type »

FVY



NOTE: Optional adaptor box is required to install the adaptor.